

Trumbull Manufacturing

3850 Hendricks Road, Youngstown, Ohio 44515

Phone: 330.270.7888 | 877.504.1507

Toll Free:


330.392.0756

-www.trumbull-mfg.com




US Patent No.'s 8,550,115 / 9,347,583 / 10,066,760

Valve Position Indicators



- Eliminates broken valve stems caused by over-opening or over-closing
- Field-adjustable for any number of turns within the range of each model





- Third-party tested to over 1 million revolutions
- Provided with stainless steel hardware
- Also available for use above ground in the floor or with Wall Brackets (see pages F-7 to F-10)

- 7. Specify direction of open (open left or open right)
- 2. Model required (available in 57, 275 or 870 turns)

Model	Number	Open Left	Open Right
Number	of Turns	Item №	Item №
57T	0 - 57	367-9404	367-9403
275T	0 - 275	367-9406	367-9405
870T	0 - 870	367-9410	367-9409

- 3. Extension Stem required (round)
 - a. Length required (provide "A" dimension on the illustration shown on right side of page F-6)
 - b. OD required (maximum OD of 1.75")
 - c. Carbon steel or stainless steel
- 4. Debris Shield, item 367-9415 recommended for buried service



Trumbull Manufacturing

3850 Hendricks Road, Youngstown, Ohio 44515

Phone: 330.270.7888 | 877.504.1507

Toll Free:

Fax: 330.392.0756

www.trumbull-mfg.com

Standard 5-1/4" Valve **Exploded Views** Box Lid of Round Extension Stems for Buried Service Debris Shield Standard 5-1/4" Valve 2" Operating Nut Box Lid w/set screw Position Indicator Debris Shield Square Stub 2" Operating Nut Shaft* w/pin Position Bronze Bushing Indicator w/pin Bronze Bushing Housing Adapter Housing Adapter Round x Square Coupling w/pins Round Extension Round Stem Extension

"A" Top of 2" nut to grade*

* The dimension from top of 2" valve nut to grade is used to determine Extension Stem length, per ordering instructions on page F-5.



US Patent No.'s 8,550,115 / 9,347,583 / 10,066,760

ROUND EXTENSION STEM

or **ROUND EXTENSION STEM** with Square Stub Shaft*

Stem

Wrench Nut

Coupling

w/pin*

- * Using a square stub shaft saves field drilling and installation of pins inside housing adapter.
- ** Wrench nut coupling normally furnished pinned to stem.

Extension Stem Torque Ratings

Consult your Trumbull Rep for torque ratings.





Installation animations online: www.youtube.com/trumbullmfg

Wrench Nut

Coupling

w/pin**